
| MXC Smart-Tactor™ 600+ AMP, 48 VOLT CAN-BUS CONTACTOR

Introduction

Contactor with CAN Bus communication reporting current, voltage, temperature, status, cycle count, and more. Other features include overcurrent trip points, undervoltage and overvoltage setpoints, power-up state, and delay-on break.



Features

• Chassis level power terminals – No need for specially routed power cables, special bus bars, or unique lugs.

Sensata

Technologies

- Rugged ceramic seal rated to 175°C Reduced risk of fire or meltdown in over current conditions. The same technology used for advanced aerospace programs.
- Hermetically sealed gas filled chamber Designed to meet: UL1604 for Class I & II, Div 2 and Class III for use in hazardous locations, IP67 for temporary water immersion for 30 min, IP69K for pressure washing, SAE J1171 – external ignition protection, IS08846 for protection against ignition around flammable gasses, and MIL-R-6106.
- High Efficiency Dual DC Coils Very low continuous coil power with no EMI emissions or crosstalk on your system control power.
- Built-in coil suppression for all DC coils Eliminates the cost and engineering time to add external coil suppression.
- Orientation invariant Can be installed in any orientation without a reduction in performance



SPECIFICATIONS

Series		15 (350 A)	16 (600 A)	
Contact Arrangement		SPST-NO (Form X) – Silver Alloy		
Contact Voltage Rating		12-48 V		
Insulation Resistance (A1	-A2, A1&A2 to controls)	rols) 500 V, 100 MΩ (50 MΩ after life)		
Dielectric (A1-A2, A1&A2 to controls)		2200 VAC, 60 Hz, leakage <1 mA		
Contact Resistance ¹	Мах	0.4 mOhm	0.3 mOhm	
	Typical	0.15 to 0.3 mOhm	0.11 to 0.2 mOhm	
Current (see chart for Temp. derating)		350 A (400 MCM)	600 A (500 MCM)	
90s		1000 A	1500 A	
10s		2000 A	3000 A	
1s		3000 A	4000 A	

Resistive Load Switching

Series	15 (350 A)	16 (600 A)	
Mechanical Life (no load switching)	300,000 cycles		
Resistive switching @ 28V	100,000 cycles @ 350 A	100,000 cycles @ 600 A	
Fault interrupt (1 cycle)	3000 A	5000 A	



Environmental Specifications

Series		15 (350 A)	16 (600 A)	
Weight		1.6 lbs, 725 g	2 lbs, 910 g	
Shock		20 G		
Vibration		15 G		
Ambient Temp Range	Operating ⁴	-55 to +85 °C		
	Storage	-70 to +150 °C		
Max Terminal Temperature		125°C		
Environmental Seal		Exceeds IP67 & IP69K		
Salt Fog		MIL-STD-810		

Timing (Max Values @ 25°C)


Series		15 (350 A)	16 (600 A)	
Operate Time ²	Max	20 ms		
	Typical	13 ms		
Release Time, Max		12 ms	7 ms	
Operate (including bounce)	rate (including bounce) 20 ms		ms	
Inrush		75 ms		

Coil Ratings (25°C, Currents & Power At Nominal V)

Series	15 (350 A) 16 (600 A)			00 A)
Coil P/N Designation	В	C	В	C
Coil Voltage (Nominal)	12 V	24 V	12 V	24 V
Coil Voltage (Max)	16 V	32 V	16 V	32 V
Coil Voltage (Min) ^{5, 7}	9 V	17 V	9 V	17V
Inrush Current (Max) ^{5, 6}	3.9 A	1.6 A	3.8 A	1.9 A
Hold Current after Inrush (Max) ⁶	0.23 A	0.097 A	0.64 A	0.32 A
Coil Hold Power (Max) ⁶	2.8 W	2.3 W	7.7 W	7.8 W
Coil Back EMF ⁹	0 V			
Transients on Power Pins (2, 7)	+50 V, 13 ms			
Vin Power Pins (2, 7) Reverse Polarity (Max)	-80 V			
For coil temperature info please see App Note	#8	#9	#12	#13









SOFTWARE PARAMETERS

Parameter	Data	
Current Trip Setting Range	± (20 A - 600 A)	
Current Sense Accuracy	±7%	
Over Current Response Time	2 ms + release time	



DIMENSIONS

All dimensions are +/- 0.5mm unless otherwise shown.

Mounting

M6 Bolts

Case Material


DuPont Zytel FR50 (25% Glass Filled Nylon)


Power Connection

Zinc Plated M12x1.75 Bolt Stainless M12x1.75 Flanged Nut Torque 23-34Nm [200-300in-lb]

Mating Connector


Gigavac offers the required mating connector as an assembled unit (0857-9/10) or as a component package, see Accessories. Deutsch Connector Housing P/N: DT06-08SA Solid Contact Socket P/N: 0462-201-16141 Wedge Lock P/N: W8S Sealing Plug P/N: 114017 Crimp Tool P/N: HDT-48-00












To enable internal 120 Ω CAN termination: Jumper Pin1 and Pin5.



ORDERING OPTIONS		Example : MXC15BEBV
<u>MXC1 5 B E</u>	<u> </u>	
Family ———		
MXC1		
Rating		
5=350A 6=600A		
Coil Voltage		
B=12 Vdc, Internal Coil Suppression C=24 Vdc, Internal Coil Suppression		
Connector		
E=DEUTSCH DT08 CONNECTOR		
Auxiliary		
B=SPST, NO X=NONE		
Voltage Sensing		
V=Sensing X=None		





- 1. Contact resisitance measured at currents higher than 100A.
- 2. Operation time is measured at 25°C and includes maximum 7ms bounce.
- 3. Insulation resistance is 50 Mohms after life.
- 4. Contactor can operate up to 125°C ambient in special cases as long as the max terminal temperature is not exceeded.
- 5. Contactor has two coils. Both are used for pick-up, and then in approximately 75 milliseconds, one coil is electronically removed from the coil drive circuit. The remaining coil supplies low continuous hold power sufficient for the contactor to meet all of its specified performance specifications. This provides low coil power without PWM electronics that can cause EMI emissions and/or cross-talk on control power.
- 6. Contactor is operated by a coil that changes resistance with temperature. Since inrush current, hold current and coil hold power are specified at nominal voltage, they will be lower than indicated at temperatures above 25°C and higher than indicated at temperatures below 25°C. Similarly, pick-up and drop-out voltages will be higher than indicated at temperatures above 25°C and lower than indicated at temperatures below 25°C.
- 7. The coil voltage cannot be ramped. It must be applied instantly at the required voltage and duration to ensure proper operation.
- 8. Limit make current to the rated continuous current to avoid contact welding.
- 9. Coils are switched internally with a FET, so no fly-back/suppression voltage is seen at the coil inputs.
- 10. The CAN communication protocol and .DBC file can be found on our website.



TECHNICAL NOTES

- Switching lifecycles is based on current flow from A1(+) to A2(-). For best breaking performance, the contactor should be installed so that current flows from A1(+) to A2(-). Break current flow in the opposite direction will result in reduced performance during break and will consume the useful life of the contactor much faster. Direction of current flow is not relevant during make or when flowing on closed contacts.
- 2. Applications with capacitors will require a pre-charge circuit.
- Electrical life rating is based on resistive load testing with 27µH maximum inductance in the circuit. Because each application is different, it is highly recommend to test the contactor under worst-case operating conditions to ensure the performance meets your application requirements.
- 4. Contactor end-of-life (EOL) is defined as when the dielectric, insulation resistance, or contact resistance exceeds the specifications listed.

Sensata Technologies, Inc. ("Sensata") data sheets are solely intended to assist designers ("Buyers") who are developing systems that incorporate Sensata products (also referred to herein as "components"). Buyer understands and agrees that Buyer remains responsible for using its independent analysis, evaluation and judgment in designing Buyer's systems and products. Sensata data sheets have been created using standard laboratory conditions and engineering practices. Sensata has not conducted any testing other than that specifically described in the published documentation for a particular data sheet. Sensata may make corrections, enhancements, improvements and other changes to its data sheets or components without notice.

Buyers are authorized to use Sensata data sheets with the Sensata component(s) identified in each particular data sheet. HOWEVER, NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER SENSATA INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY THIRD PARTY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT, IS GRANTED HEREIN. SENSATA DATA SHEETS ARE PROVIDED "AS IS". SENSATA MAKES NO WARRANTIES OR REPRESENTATIONS WITH REGARD TO THE DATA SHEETS OF THE DATA SHEETS, EXPRESS, IMPLIED OR STATUTORY, INCLUDING ACCURACY OR COMPLETENESS. SENSATA DATA SHEETS ANY WARRANTY OF TITLE AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OUIET ENJOYMENT, QUIET POSSESSION, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS WITH REGARD TO SENSATA DATA SHEETS OR USE THEREOF.

All products are sold subject to Sensata's terms and conditions of sale supplied at www.sensata.com SENSATA ASSUMES NO LIABILITY FOR APPLICATIONS ASSISTANCE OR THE DESIGN OF BUYERS' PRODUCTS. BUYER ACKNOWLEDGES AND AGREES THAT IT IS SOLELY RESPONSIBLE FOR COMPLIANCE WITH ALL LEGAL, REGULATORY AND SAFETY-RELATED REQUIREMENTS CONCERNING ITS PRODUCTS, AND ANY USE OF SENSATA COMPONENTS IN ITS APPLICATIONS, NOTWITHSTANDING ANY APPLICATIONS-RELATED INFORMATION OR SUPPORT THAT MAY BE PROVIDED BY SENSATA.

Mailing Address: Sensata Technologies, Inc., 529 Pleasant Street, Attleboro, MA 02703, USA.

Americas

Sensata GIGAVAC Contactor Center of Excellence 6382 Rose Lane Carpinteria, CA 93013 USA

Tel: +1 (805) 684 8401 Email: gigavac@sensata.com Sensata Global Headquarters Sensata Technologies 529 Pleasant Street Attleboro, MA 02703 USA

Europe, Middle East & Africa

Sensata Technologies Holland B.V. Jan Tinbergenstraat 80 7559 SP Hengelo The Netherlands Tel: +31743578000 Email: gigavac-info-eu@list.sensata.com

CONTACT US

Asia Pacific

Sensata Technologies China Co., Ltd. BM Intercontinental Business Center 30th Floor 100 Yu Tong Road Shanghai 200070 People's Republic of China Tel: +8621 2306 1500 Email:contactorasia@list.sensata.com Japan Sensata Technologies Japan Ltd. Shin Yokohama Square Bldg. 7F 2-3-12 Shin-yokohama Kohoku-ku, Yokohama-shi, Kanagawa 222-0033 Tel: +81 45 277 7001 Email:contactorasia@list.sensata.com

www.sensata.com